








Dishwasher

Operation (push buttons)

1	On/off	Push this button to turn on your dishwasher, the screen lights up
2	Half-load	If you do not have too much load, you might consider using the half-load program. This function saves water and energy. It can be used with the programs Intensive, Universal, ECO and 90 min.
3	Delayed start	Press this button to set a delayed start.
4	Program	Select the appropriate washing program. The corresponding indicator will be lit.

Indicators

5	Program indicator	 65°  55°  45°  90° 60°  50°	<p>Intensive Heavily soiled items include pots and pans. With dried on food.</p> <p>Universal For normally soiled loads, such as pots, plates, glasses and lightly soiled pans.</p> <p>ECO This is a standard program, it is suitable to clean normally soiled tableware and it is the most efficient program in terms of its combined energy and water consumption for that type of tableware.</p> <p>90 min For normally soiled loads that need quick wash.</p> <p>Rapid A shorter wash for lighty soiled loads that do not need drying</p>
6	Warning indicator	 	<p>Rinse aid If this indicator is lit, it means the dishwasher is low on dishwasher rinse aid and requires a refill.</p> <p>Salt If this indicator is lit, it means the dishwasher is low on salt and needs to be refilled.</p>
7	Delayed start time		To show the delayed start time (3h/6h/9h)