

Gebruiksaanwijzing:

1. Kies toestel 1 tot 6 (1, 2- drogers, 3,4,5,6- wasmachines)
2. Doe uw wasgoed in de juiste machine en sluit de deur
3. Kies uw wasprogramma
4. Selecteer op de terminal het nummer van de machine die u wilt gebruiken, voer uw telefoon of betaalkaart in en wacht op de bevestiging van de betaling
5. Druk na bevestiging van betaling op de START-toets om het wassen te starten.

Prijslijst:

Wasmachine- EUR 5,50 per wasbeurt

DROGEN –EUR 4,00 per wasbeurt

Dank u en nog een prettige dag!

Contactless payment**Instructions for use:**

1. Choose appliance 1 to 6 (1, 2- dryers, 3,4,5,6- washers)
2. Put your laundry in the correct machine and close the door
3. Choose your washing programme
4. Select on the terminal the number of the machine you want to use, enter your phone or payment card and wait for the payment confirmation
5. After confirming payment, press the START button to start the washing.

Price list:

washing machine- EUR 5,50 per wash

DRYING - EUR 4,00 per wash

Thank you and have a nice day!