Thermostat instruction manual

Check the type of thermostat in the overview and follow the instructions.

Please note! The heating panels in the bedroom should be switched on via the thermostat in the bedroom or via the buttons on the side of the heating panel.

Type of Instructions thermostat Left arrow: Lower the temperature. Central button (blue): Confirm a question or selection. Right arrow: Increase the temperature. TIP: If the display is dark or dimmed, it can be activated by touching one of the keys. Caution! Do not change anything in the heating settings. + with up arrows: Increase the temperature. - with down arrows: Decrease the temperature. When you set the temperature, you will see (as long as the 'C' symbol is flashing) the set temperature. Then the current temperature in the room is displayed. Note! If a room is not used for an extended period, it will cool down to the anti-frost temperature due to the energy-saving operation of the ICY Timer-Thermostats. In the living room, the temperature will drop if no movement is detected. Switch the thermostat on or off with the Power button: When the word ROOM is displayed, the number below it indicates the current temperature in the room in °C; When the word SURFACE is displayed, it indicates the current temperature of the heating surface (floor, ceiling) in °C. When the word SET is displayed, it indicates the current temperature of the room or heating surface and when pressing - and + , it indicates the temperature to be reached. Heating/flame icon: If the set temperature of the thermostat is higher than the current temperature of the room or heating surface, the Heating icon is shown active.



Switch the thermostat on or off with the Power button: (1)

Adjust the temperature using the ▲ (increase temperature) and ▼ (decrease temperature) buttons. Then press the round O (left button) to confirm the temperature and then press the arrow ⊃ back.



You can turn the switch on by turning the knob up to | dash. You can turn the thermostat off by turning the knob down to 0 (round).

You can adjust the temperature by turning the round knob (right side). If the red light is on, the heating is on.



You can easily operate the thermostat via the touchscreen. You can control the temperature using the + and - buttons + with up arrows: Increase the temperature.

- with down arrows: Decrease the temperature.

After setting the temperature, the current temperature in the room is shown on the display.

TIP: If the display is dark or dimmed, it can be activated by touching one of the buttons.

Questions about the thermostat?

Stop by or call reception during opening hours: 088 0708296

Outside reception opening hours, call: +31643394432