


# Hottub Manual

## EuroParcs De Utrechtse Heuvelrug



Nr.	Description	Explanation
1.	Display	The display shows the desired temperature (right) and the current temperature (left). In the event of a malfunction, an error code is displayed here.
2.	On/off indicator	This light is on when the device is on.
3.	Burner on/off indicator	This light lights up when the burner is on.
4.	Overheat indicator	This light comes on when the water in the hot tub is hotter than 50 degrees. The burner is then switched off.
5.	On/off button	With this button you can turn the device on or off.
6.	Temperature control	With these buttons you can set the desired temperature of the water.
7.	Water level indicator	This light comes on when the water level is too low or when there are air bubbles in the device.
8.	Burner malfunction	This light comes on when the burner is in a fault state or stops during use.

# Instruction

## Preparing the hottub for use

1. Open the heater (gray cabinet) with the key you received at check-in.
2. Turn on the heater by pressing the "POWER" button. (5)
3. Set the desired temperature using the "UP" and "DOWN" buttons. (6)

*a. You will see 2 temperatures on the display. On the left is the current temperature. On the right is the desired temperature. We recommend keeping the temperature between 35 and 40 degrees.*  
*b. If the water is not yet at the desired temperature, the burner turns on to heat the water. This can be seen by the "BURN" light coming on. (3)*

4. It takes +/- 60 minutes to heat the water to the desired temperature, depending on the base temperature of the water.

*a. Tip: the water heats up faster if you leave the lid on the hot tub while heating.*

5. Once the water has reached the desired temperature, you can use the hot tub. Leave the heater on to keep the water at the right temperature.

## To turn the hottub after use:

1. When you have finished using the hot tub, turn off the heater by pressing the "POWER" button. (5)
2. Close the hot tub with the lid.

### **In case of a empty fuel tank:**

1. Buy the first consumption (25 euros) at the reception. The actual consumption depends on how often the whirlpool is switched on and off and to what temperature it is heated.
2. Would you like to use the whirlpool more often or for longer? Please contact our reception and we will fill up the tank for 25 euros.

## In case of problems

1. If you experience any problems with the use of the hot tub, please report them to our reception. We will be happy to resolve the problem for you quickly.

**PLEASE NOTE: We kindly request that you fill and empty the hot tub yourself. This can be done using the garden hose that can be connected to the outside tap of your accommodation.**