

TELEVISION OPERATION

You have 2 remote controls available.

- A) The black remote control is for the TV lift to bring the TV screen up and down.
- B) The beige remote control is for the TV itself.

A) De TV-lift

Press button **1** and the TV lift goes up.

Press button **2** and the TV-lift goes down.

The start and final positions are programmed, so you don't have to do anything else.



Figure 2 TV-Remote control




Figure 1 TV Lift

B) The TV remote control

Press key **1** to switch on the device.

If necessary press key **2** to start the TV transmitter.